



Extra-Long Motorcycle Ramps

Instructions for Part # BW-12040-HD, BW-14440-HD

General Guidelines ⚠

- It is the user's responsibility to read and follow all instructions.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure it is assembled properly and all parts are in safe working order and free of defects.
- Never modify this product in any way.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measures when using this product.
- Parts and/or instructions are subject to change without notice.

Safety ⚠

- Never exceed the maximum weight limit displayed on the side of the motorcycle ramp.
- Never over-accelerate. Operator must be in control of vehicle at all times. Loss of control could result in injury.
- The manufacturer and/or dealer is not responsible for any property damage or personal injury that occurs from improper use.
- Clean the ramp and motorcycle of debris before loading and unloading the motorcycle.
- A helmet must be worn when loading and unloading vehicles using the motorcycle ramp.
- Store the motorcycle ramp in a safe dry place.
- Never use the ramp on a unsafe or damaged tailgate, trailer, or other loading surface.
- Thoroughly inspect tailgate cables and ramp safety straps for cracks or fraying.

Maintenance

Straps:

- Check straps for fraying and wear - do not use damaged straps/
- Keep out of direct sunlight.
- If wet, dry thoroughly before storing.

Ramps - Before each use:

- Check all ramp bolts and nuts for tightness before each use.
- Inspect ramps for damage - do not use damaged or bent ramps.

Assembly

Before assembling, check the included hardware for correct parts and quantities.



Part	Description	Quantity
A	C-Beam Brackets	8
B	Spring Clip Pins	8
C	Safety Straps	3

1. Stand all three ramp pieces on ends, folded in the center.
2. Install eight C-beam brackets along the ramps. Four upper, four lower. (Figure 1)
3. With the side ramps properly in place, lock in place using the spring clip pins. (Figure 2)

Figure 1



Figure 2



Preparation for Loading

1. Park truck or trailer on firm, flat ground.
2. Remove any obstructions from truck/trailer bed.
3. Check tailgate cables/brackets for damage or wear. If tailgate is not sturdy or cables are damaged, do not continue.
4. Unfold ramps and place the ramp snugly on the tailgate with the end plate lip overlapping the tailgate. (Figure 3)

Securing Ramps

1. Before each use, check straps for fraying and wear. Do not use damaged straps.
2. Loop the strap around the center section of the ramp just below the second rung. (Figure 4)
3. Find a secure place to hook the safety strap. Tow hitch points or bumper supports are recommended. Hook both ends of the strap to the vehicle/trailer. (Figure 5)
4. Tighten the strap until tight and ramp is secure against the tailgate/trailer.
5. Repeat Steps 1-4 with the second strap.

Loading

1. If possible, have a second person help loading.
2. Start motorcycle; allow it to run to ensure it doesn't stall on the ramp.
3. Position the motorcycle to ride up the center of the ramp. Slowly ride up the ramp; keep hand near the brake and be ready to put feet down in case of stall. Acceleration must be slow, smooth, and constant. **WARNING: Never over-accelerate! Operator must be in control of vehicle at all times. Loss of control could result in injury.**
4. Stop when motorcycle is in truck bed/trailer.
5. Secure motorcycle to truck/trailer. Remove ramp and straps.

Unloading

1. If possible, have a second person help unloading.
2. Follow steps from Preparation for Loading and Securing Ramps.
3. Clear the unloading area behind the ramp.
4. Sit on the motorcycle with hand on brake. Put up kick-stand.
5. With motorcycle OFF and in NEUTRAL, slowly back down the ramp in a walking motion, letting the brake slip.
6. Park the bike. Remove ramp and straps.

Figure 3




Figure 4



Figure 5



Product Warranty and Liability

GENERAL PRODUCT WARRANTY: Products purchased from the Authorized Dealer (original place of purchase) or Merchant (“Dealer”) will be free of defects in material and workmanship at the time of receipt, and will meet the specifications stated at the place of purchase transaction or online at the Dealer’s website, under normal use and service when correctly installed, operated and maintained. This product warranty is effective for the period of time stated below, unless otherwise stated in the product instructions or depicted in the product advertisement. **All Authorized Dealer warranties are NON-TRANSFERABLE** and cover only the original end purchaser. This limited warranty does not cover products purchased through non-authorized dealers. Non-authorized dealer receipts are not accepted for warranty verification.

Warranty claims must be made directly to the original place of purchase.

WARRANTY PERIOD: This warranty remains in force for one year from the date of the product’s accepted delivery. The Authorized Dealer offers a one year manufacturer’s warranty for most products unless otherwise specified on the product advertisement.

WARRANTY SERVICE: The Authorized Dealer will replace any defective or malfunctioning part at no charge, including payment of the shipping costs of parts or replacement product to and from the manufacturer. The purchaser is responsible for labor charges. If the product does not meet specifications as depicted in the advertisement, the Authorized Dealer will refund the full purchase price of the product.

Questions regarding the warranty on a specific product and warranty claims should be directed to the Authorized Dealer with whom the purchase transaction was made.

WARRANTY LIMITATIONS: The above warranty does not apply to products that are repaired, modified or altered by any party other than the Authorized Dealer; are subjected to unusual physical stress or conditions (such as overloaded ramps or corrosion), natural disaster, governmental actions, wars, strikes, labor disputes, riots, theft, vandalism, terrorism or any reason beyond reasonable control; are damaged due to improper installation, misuse, abuse, accident or negligence in use, storage, transportation or handling, or tampering; or to products that are considered consumable items or items requiring repair or replacement due to normal wear and tear.

Product should be inspected prior to signing for delivery. Product damage incurred during shipping, unless noted on the Bill of Lading at the time of delivery, renders this warranty void.

LIMITED LIABILITY: In no event shall THE AUTHORIZED DEALER be liable to the purchaser or any third party for any indirect, incidental, consequential, special, exemplary or punitive damages arising out of the use of the product, including, without limitation, property damage, loss of value of the product or any third party products that are used in or with the product, or loss of use of the product or any third party products that are used in or with the product.

